

CORBY

IRONS

This manual is for the following models:

IRN0002
2555
2557

IRN0004
2554
2556

IRN0003
Y-876A-2

IRN0005
Y-832A-1

www.corbyofwindsor.com

www.firedupcorporation.com/manual

These notes must be read before use

These instructions are for your safety. Please read through them thoroughly before use and retain for future reference. Failure to follow them could cause injury and/or property damage. These instructions are also available on our website.

CONTENTS

SECTION 01

Important safety	03-04
Special instructions	05

SECTION 02

Introduction	06
Identification	06-07

SECTION 03

Use	08
Care	09
Specification	09
Plug Replacement	10
Guarantee	12
Contacts	12

IMPORTANT SAFETY INSTRUCTIONS

DO'S

-
- Read ALL the instructions before using this appliance.
-
- Only use this appliance for its intended use as described in this manual.
-
- Check your mains supply is the same as that indicated on the product before connecting *and* only connect to an earthed socket outlet.
-
- Fully unwind the supply cord before plugging into the wall socket.
-
- Always disconnect the iron from the electrical outlet when not in use.
-
- Never leave the iron unattended while it is connected to the mains supply.
-
- The iron must only be used and rested on a stable surface.
-
- When placing the Iron on its stand, ensure that the surface on which the stand is placed is stable.
-
- Always keep the iron and its cord out of reach of children less than 8 years of age when it is energized or cooling down.
-
- Always disconnect the appliance from the electrical supply before carrying out cleaning or maintenance.
-
- Check the iron and the cable for damage regularly.
-

DON'TS

-
- The appliance is designed exclusively for its intended purpose and is not intended for heavy commercial use.
-
- Never allow the supply cord to touch hot surfaces.
-
- Never use the appliance in a bathroom or near any source of water.
-
- Do not use or store the appliance outdoors.
-
- Never immerse the iron in any water or other liquids. Do not use this appliance with wet hands. If the appliance is wet, unplug it.
-
- The ironing base becomes hot very quickly and takes a long time to cool down. Please do not touch it. Never iron clothes while they are being worn.
-
- Never use the iron if it has been dropped or if there are visible signs of damage
-
- Do not attempt to make repairs to the appliance. Always contact a qualified technician.
-

IMPORTANT!

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.

Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.

Children shall not play with the appliance.

Check the appliance and the supply cord for damage regularly.

If the supply cord becomes damaged, it must be replaced by a suitably qualified person using the same rated cable. Do not attempt to make repairs to the appliance.

When cleaning, or storing away, always pull out the plug from the socket outlet. Never yank the cord to disconnect from the outlet, instead grasp the plug and pull to disconnect.

Avoid the use of an extension cord which may overheat and cause risk of fire.

If an extension cord is absolutely necessary, the cord should be a three wire cord with a grounding type plug and cord connection. It must be rated above the maximum rated power of the appliance.

SAVE THESE INSTRUCTIONS


INTRODUCTION

Thank you for choosing this Corby iron. The product has been designed to meet the most stringent quality, performance, and safety requirements. This iron is perfectly suited to the requirements of a hotel guestroom.

IDENTIFICATION

1200W Dry iron


IRN0002 / 2555 / 2557



- | | |
|---------------|-------------------|
| 1. Soleplate | 5. Cable entry |
| 2. Skirt | 6. Upper cover |
| 3. Body | 7. Control lamp |
| 4. Rear cover | 8. Temp regulator |

1200W Steam iron


IRN0004 / 2554 / 2556



- | | |
|--------------------|---------------------|
| 1. Soleplate | 7. Upper cover |
| 2. Skirt | 8. Spray button |
| 3. Temp regulator | 9. Steam jet button |
| 4. Body/water tank | 10. Steam knob |
| 5. Control lamp | 11. Water inlet |
| 6. Cable entry | 12. Spray nozzle |

1600W Steam iron


IRN0003 / Y-876A-2



- | | |
|--------------------------|------------------|
| 1. Soleplate | 8. Spray button |
| 2. Skirt | 9. Steam control |
| 3. Temperature regulator | 10. Water inlet |
| 4. Control lamp | 11. Handle cover |
| 5. Rear cover | 12. Spray nozzle |
| 6. Cable tube | 13. Front cover |
| 7. Steam jet button | 14. Water tank |

2000W Steam iron

IRN0005 / Y-832A-1



- | | |
|--------------------------|---------------------|
| 1. Soleplate | 9. Steam jet button |
| 2. Skirt | 10. Spray button |
| 3. Slef cleaning button | 11. Steam control |
| 4. Temperature regulator | 12. Water inlet |
| 5. Control lamp | 13. Handle cover |
| 6. Rear cover | 14. Spray nozzle |
| 7. Non slip handle | 15. Front cover |
| 8. Cable tube | 16. Water tank |

USE

BEFORE USE

- Please read all the Important Safety information and the Instructions for use.
- Remove all packaging from the iron.
- It is normal for some smoke and a light odour to be emitted at first use, this is not a fault.

ATTENTION! *Only iron garments with this appliance.*

IRONING WITHOUT STEAM

1. Sort the garments according to their ironing temperatures. Start with the lower temperatures using the temperature regulator
 - Synthetics, silk (low temp)
 - Wool (med temp)
 - Cotton, linen (high temp)
2. Insert the mains plug into a socket outlet.
3. The control lamp lights up. As soon as it shuts off, the set temperature is reached (approx. 1-2mins). Now you can iron.
4. When the iron is not in use always unplug the appliance from the mains.

IRONING WITH STEAM

1. Using the filling beaker (provided), fill the water tank through the water inlet with pure water.
2. Please use distilled water instead if the water is harder than previously stated.
3. Turn the steam knob to '☁' or "☁", in order to begin steam ironing.
 "☁" or "☁" - max position
 "✕" or "0" - off position

STEAM JET FUNCTION

1. Turn off the steam knob first.
2. Turn the temp regulator to max position.
3. After the indicator goes off, press the steam jet button.
4. At most, it can release steam 5-7 times continuously (approx. pressing the button once every second).

AUTO SHUT-OFF FUNCTION

- The iron will automatically shut off if left standing still and the auto shut-off lamp will flash.
- In upright position it will auto shut-off after 8 mins.
- In horizontal position it will auto shut-off after 30 secs.
- To switch the iron on again, simply move the iron.

CARE

Always allow the iron to cool down completely before storing the appliance away.

We recommend the water is emptied from the appliance before storing.

To protect the soleplate, we recommend storing the iron on its heel.

When cleaning, or storing away, always pull out the plug from the socket outlet. Never yank the cord to disconnect from the outlet, instead grasp the plug and pull to disconnect.

- Always unplug the iron before cleaning and allow to cool completely.
- Clean the iron with a slightly damp cloth.
- Do not use any abrasive cleaning agents.
- To clean the iron and remove deposits of starch or water soluble, rub the soleplate with a soft cloth soaked in vinegar and water.

SPECIFICATION

Model No:	IRN0002 2555 2557	IRN0004 2554 2556	IRN0003 Y-876A-2	IRN0005 Y-832A-1
Rated Voltage	220-240V	220-240V	220-240V	220-240V
Rated Frequency	50-60Hz	50-60Hz	50-60Hz	50-60Hz
Rated Power	1200W	1200W	1600W	2000W
Temperature Range	65-230°C	65-230°C	65-230°C	65-230°C
Water Volume	N/A	145ml	250ml	300ml
Weight	570g	750g	1100g	1200g
Steam Shot	N/A	15g	34g	34g
Soleplate Size	155 cm2	155 cm2	165cm2	199cm2
Accessory	None	One cup	One cup	One cup

PLUG REPLACEMENT

(for Product fitted with BS plug)

This appliance is supplied with a BS1363 3-pin plug fitted.

1200W Irons come with a 7 Amp fuse.

1600W Irons come with a 10 Amp fuse.


2000W Irons come with a 10 Amp fuse.

Should the fuse require replacement, it must be replaced with a fuse rated corresponding to that stated above and approved to BS1362.

In the event the mains plug has to be removed/replaced for any reason, please note:


The wires in the mains lead on this appliance are coloured in accordance with the following code:

Green and Yellow - Earth
Blue - Neutral
Brown - Live



THIS APPLIANCE MUST BE EARTHED

As the colours may not correspond with the markings identifying the terminals in your plug proceed as follows.

- The green and yellow earth wire must be connected to the terminal in the plug which is marked with the letter E or with the earth symbol 
- The blue wire must be connected to the terminal marked N
- The brown wire must be connected to the terminal marked L

IMPORTANT - any cut off plug should be disposed of safely to prevent hazard. There is a danger of electric shock if a cut off plug is inserted into a socket outlet.

CONFORMITY WITH DIRECTIVES

Conforms with relevant European Directives

ENVIRONMENTAL PROTECTION

- (WEEE) Waste Electrical and Electronic Equipment

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

- This appliance complies with the RoHS directive which restricts the use of certain hazardous substances in electrical and electronic equipment. This directive bans the placing on the EU market of new electrical and electronic equipment containing more than agreed levels of lead, cadmium, mercury, hexavalent chromium, polybrominated biphenyl (PBB) and polybrominated diphenyl ether (PBDE) flame retardants.



GUARANTEE

For your convenience, you are not required to complete a form and return it to us in order to validate your guarantee. However, please ensure that you retain your receipt which will act as both proof of purchase and a guarantee validation document. **We recommend that you attach your receipt to this documentation.**

Your product carries a minimum 12 month guarantee from the date that the original purchaser receives it. If your product fails to operate to its specification due to faulty workmanship or materials during the guarantee period, we will either repair or replace the product. We will use our discretion to determine whether to offer a repair or provide a replacement. The product will not be covered by the guarantee if it has been misused, transformed, modified or altered in any way.

If your product fails within the guarantee period please ensure that you have all necessary documentation available including proof of purchase (receipt or invoice with serial number, location and date of purchase) in addition to all original undamaged packaging and leaflets etc. It is strongly recommended that you inspect your product carefully before it is used or installed. For full details of your product you should refer to the instruction manual which accompanies the product. You are strongly advised to read this manual carefully in its entirety and to retain it for future reference.

This product guarantee does not affect your statutory rights.



www.firedupcorporation.com

Fired Up Corporation Ltd
Fired Up Buildings
HD1 3LF, UK

Fired Up Corporation
(Ireland) Ltd
71, D02 P593, Dublin